LD5200

Firmware Version	Features	Release Date
v2.3.3	> Corrected "Master Zone Map" test map zone numbers when unit is set to meters.	2/2/2021
v2.3.2	Corrected "Master Zone Map" zone numbers when unit is set to meters.Changed Bacnet CStrings for strings < 4 characters	1/28/2021
v2.3.1	> Changed SNMPv3 from option to standard	1/12/2021
v2.2.27	 Make sure bacnet leakdistance object is zero if leak is not present Bacnet leakdistance object is a minimum of 1 when a leak is present 	11/10/2020
v2.2.26	> Changed email multiple To: lines to single To: line for multiple recipients	11/1/2020
v2.2.25	 > Added processing for bacnet mstp "reply postoned" > Corrected web gui orange color on slave bacnet controllers > Add date/time header to sent emails > Corrected modbus register 30011 - virtual zones 32-17 in alarm (was always reading zero) > Add option for European time formatting > Fixed latched cable break unable to be reset from LCD screen 	10/13/2020
v2.2.19A	> Fixed LCD alarm history acknowledgements (main.c, alarmh.c, lcd.c, common.h)	12/20/2018
v2.2.19	> Fix red, blinking alarm box showing up on every nested map	10/10/2018
v2.2.18	> Corrected web page BACnet distribution table display	6/18/2018
v2.2.17	 Corrected alarm history leak distance when Modbus slaves virtual zones when in Meters Corrected Web page display of Modbus slaves virtual zone when unit is in Meters Corrected Map Alarm Coordinates - Text for Master Zone Map when unit is set to Meters 	6/13/2018
v2.2.16	> Added Cable Relay on/off to LCD > Added power fail option for the PM relay	4/19/2018