WIFI-1WIRE Quick Start Guide



Thank you for purchasing a WIFI-1WIRE wireless Wi-Fi enabled 1- wire temperature and humidity sensor transmitter. This guide details WIFI-1WIRE installation and configuration.

Before you install a WIFI-1WIRE, check the RLE website - www.rletech.com - to ensure you are using the most recent version of our documentation.

If you need further assistance, please contact RLE Technologies at support@rletech.com.





© Raymond & Lae Engineering, Inc. 2011. All rights reserved. RLE® is a registered trademark and SeaHawk™, Falcon™, and Raptor™ are trademarks of Raymond & Lae Engineering, Inc. The products sold by RLE Technologies, 104 Racquette Drive, Fort Collins, CO 80524 are subject to the limited warranty, limited liability, and other terms and conditions of sale set forth at https://www.rletech.com/

Installation Supplies _

Included with the WIFI-1WIRE

WIFI-1WIRE device - includes two 3.6V lithium batteries 1-Wire leader cable

Available from RLE, sold separately

USB-A to Micro B cable, used for configuration 1WIRE-TS or 1WIRE-THS sensor

Additional materials

Computer with a terminal interface (CLI)

Mount the Transmitter _


- 1. Remove the lid from the sensor enclosure. The lid has one large tab at the top and two small tabs at the bottom that secure it to the sensor base. Squeeze the top of the lid to release the large tab. Pivot the top of lid out from the base and gently separate the two bottom tabs from the base.
 - **NOTE:** The serial number is printed on a white label on the outside of the sensor lid. The serial number on this label is unique to each sensor and you will need to refer to this number throughout the life span of the device.
- 2. Remove the circuit board from the base to expose the mounting holes. Before you take it apart examine how the board fits into the base. You'll have to put it back into the base so make sure you have a clear understanding of how it was assembled before you remove it.
- 3. To remove the board pull the circuit board clip out to relieve the tension that holds the board in place. Angle the board up and then pull it to the right to remove it from the base. Move the board slowly and gently to get it out of the base without damaging any circuitry.
- 4. Do not mount the transmitter behind metal objects. Use the provided hardware to secure the base in the desired location.

5. Put the circuit board back into the enclosure. There are two "L" shaped brackets along the left side of the enclosure. Angle the board in under the lip of these L brackets and as far down as it will go against the plastic pegs at the bottom of the enclosure. Guide the board so it is parallel with the base. Pull the circuit board clip out and push the board down until the circuit board clip snaps into place and secures the board. The board is a very tight fit in the enclosure. Work slowly and gently so the board is secured by the enclosure and doesn't get damaged in the process.

Connect the 1-WIRE Sensor_

Connect the 1-wire cable to the transmitter. A leader cable is used to connect the 1-wire sensor to the WIFI-1WIRE, since the sensor cannot connect directly to the transmitter.

- 1. Insert the four stripped wires of the 1-wire leader cable into the appropriate slots in the 4-pin cable input terminal block connector - from left to right: black, red, green, and yellow. Tighten the screws on the terminal block connector to secure the leader
- 2. Attach the RJ11 coupler to the opposite end of the
- 3. Plug the 1-Wire probe into the other side of coupler.



Activate the Sensor_

Each sensor is equipped with two 3.6V lithium batteries which should be replaced as needed. Once the protective battery tab has been removed, the average battery life is up to 5 years at the default transmission interval. Battery life varies based on WiFi signal strength, transmission interval, and access point performance. Sensors will not operate with alkaline batteries - make sure the batteries are replaced with two 3.6V lithium cells. Safely dispose of old batteries.

The sensor is shipped with a battery pull tab in place which turns the device off. To activate the sensor, remove the protective tab to engage the batteries. Turn off the sensor by re-inserting the tab or removing the batteries. Any time the sensor is shipped, it should either be turned off or placed in a shielded container to prevent interference that might cause shipping problems.



1-Wire Leader Cable USB

Connection Button

Wiring Connection

Once the sensor is activated, put the lid back onto the sensor enclosure.

Configure the WIFI-1WIRE to Communicate on Your Network

Each WIFI-1WIRE sensor needs to be configured to communicate on your wireless network. Use a USB-A to Micro B cable and a computer with a terminal interface (CLI) to configure the sensors.

1. Use the USB-A to Micro B cable to plug the sensor into a computer.

- 2. Access the computer's CLI: 115200 baud, 8 data bits, 1 stop bit, no parity.
- 3. Connect the sensor to a wireless network. There are two ways to do this:

Option 1: Select a network from a list of available options

- a. Enter "C" at the prompt to configure a wireless network.
- b. Enter the number that corresponds with the desired network.
- c. If the network has security, enter the password when prompted.

Option 2: Configure a network manually

- a. Enter "S" at the prompt to enter your network's SSID.
- b. If the network has security, enter "P" to set the network password.
- c. Enter "A" to set a network security type.
- 4. Configure your network. There are several ways to do this:

Option 1: Use a DHCP IPv4 network

a. Enter "D" at the prompt and then enter "1" to enable DHCP.

Option 2: Use a static IPv4 network

- a. Enter "D" at the prompt and then enter "0" to use a static network.
- b. Enter "I" at the prompt to set the IP address of the sensor.
- c. Enter "N" to set the netmask.
- d. Enter "G" to set the network gateway.

Option 3: Use a static IPv6 network

- a. Enter "M" at the prompt to edit the IP mode.
- b. Enter "1" to select IPv6 Static.
- c. Enter "I" to set the global IPv6 address of the sensor, if applicable.
- 5. Enter "B" to set the IP address of the BMS system or WiNG-MGR.
- 6. Enter "X" to transmit a test packet.

Sensor LED

There are several alarm and alert patterns and colors programmed for the LED. The LED is almost always off during standard operation and is primarily active during sensor configuration and reset sequences.

Color			Status Description	
		Blue Solid	Ready	
		Quick Blue/ Green Flash	Once every transmission interval. Sensor is successfully connected to wireless network	
		Quick Red/ Blue Flash	Failed wireless connection	
		Purple Blink	Factory reset in progress	

Sensor Push Button

The sensor's push button is located next to the LED and is used to reset the sensor to its original factory settings.

If you'd like to reset the sensor, it **must** be connected to a computer via the USB cable. Push and hold the button for 10 seconds. A countdown will be displayed in the terminal emulation software, and the LED will flash purple to indicate the sensor is being reset. Once the reset is complete, the sensor LED will glow blue.

You can also press the button once to send a single packet once the sensor is configured on your network and the USB cable is unplugged from the sensor.

Terminal Interface (CLI) Commands

The following basic commands are available for the WIFI-1WIRE via a CLI on your computer:

```
COM18-Tera Term VT

File Edit Setup Control Window Help

WIFI-1WIRE v2.0 - Built Oct 19 2020 08:27:06 WDC 0

MAC ID = 3C:A3:08:02:B8:CD WiNG Serial# = 0802B8CD


Network Settings:
C) Configure a wireless network
S) SSID = ""
P) Password = ""
A) Authentication = WPA2(AES) / WPA(TKIP)
D) DHCP = OFF
I) Sensor IP address = 10.0.0.188
N) Netmask = 255.0.0.0
G) Gateway = 10.0.0.1
H) IP Mode = IPU4

BMS server (or WiNG MGR) settings:
B) BMS IP address = 10.0.0.189
U) UDP port = 3184

Device settings:
W) Wake interval [minutes] = 5
Z) Device GrouplD = 0
U) Advanced Settings
X) Connect and transmit test packet
K) Save configuration
```

Pacie Commande	Description
Basic Commands	Description
Blank	Print a list of all commands
С	Configure a wireless network
S	Set wireless SSID
P	Set wireless password and device password
A	Set wireless authentication type
D	Turn DHCP on and off
I	Set IP address (if DHCP is disabled)
N	Set netmask (if DHCP is disabled)
G	Set network gateway (if DHCP is disabled)
М	Set IP mode (IPv4 or static IPv6)
В	Set BMS or WiNG-MGR IP address to receive packet
U	Designate where UDP port packet will be sent
W	Set wake interval
Z	Set group ID (will be transmitted with packet)
V	Display advanced settings
X	Transmit a test packet
K	Save configuration

The following advanced commands are primarily used by tech support for troubleshooting, and are provided here for reference only:



Advanced Commands	Description	
Blank	Print a list of all commands	
Т	Take a sensor reading View detailed version information	
V		
F	Enable fast wifi-connect	
О	Number of milliseconds to wait after connecting before sending packet	
J	Number of milliseconds to wait after sending packet before disconnecting	
Р	Battery depassification	
L	Light the LED	
Н	Manually set the packet counter	
E	Put the device to sleep for a configured amount of time	
Υ	Initiate a factory reset	
х	Return to main menu	

WIFI-1WIRE Packet Structure

*****	WIFI-IWIRE Packet Structure					
Bit Offset	0-7	8-15	16-23	24-31		
0	Status Flag (U16)		Protocol Version (U8)	MAC Address (U8)		
32		MAC Ad	dress (U8)			
64	MAC Address (U8)	Sensor Type (U8)	Packet Coun	ter (U16)		
96	Group ID (U16)		Battery Voltage (U16) Unit: centivolts Divide unit value by 100 for combined total voltage of both batteries. Example: Data value = 635 635 ÷ 100 = 6.35 Total voltage of two batteries = 6.35V Battery life guidelines: > 6.0V = Good > 5.8V = OK - replace soon < 5.6V = Poor - replace immediately			
128	Version Major (U8) Version Minor (U8)		RSSI (U16)			
160	Data 1 Data type: UINT16 *See Packet Data Definition Table below		Data 2 Data type: INT16 *See Packet Data Definition Table below			
192	Reserved		Reserved			
224	Reso	erved	Reserved			
256	Rese	erved	Reserved			
288	Res	erved	Reserved			
320	Reserved		Packet CR	C (U16)		

WIFI-1WIRE Packet Data Definition Table

1-Wire Sensor Type	Type (U8)	Data 1 (UINT16)	Data 2 (INT16)
WIFI-1WIRE + 1WIRE-TS	0x02	N/A	Description: Sensor temperature Unit: deci °C Divide unit value by 10 for temperature reading. Example: Data 2 value = 230 230 ÷ 10 = 23 Temperature = 23°C
WIFI-1WIRE + 1WIRE-THS	0x03	Description: Sensor humidity Unit: deci % Divide unit value by 10 for humidity reading. Example: Data 1 value = 435 435 ÷ 10 = 43.5 Humidity = 43.5%	Description: Sensor temperature Unit: deci °C Divide unit value by 10 for temperature reading. Example: Data 2 value = 230 230 ÷ 10 = 23 Temperature = 23°C